

LINK AND RESET

Quick guide · How to get the Connect-1 ready to link to the app



LED

**RESET
BUTTON**

RESET BUTTON

It is inside a small hole, just above the UP button. To press it, use a paperclip or another thin object.

LED

It is the small dot just above the reset button.

If it blinks slowly (once every 2 seconds), the Connect-1 is **ready to link to the app**.

BEFORE YOU START Your Wi-Fi network must be **2.4 GHz**. 5 GHz networks do not work. The Connect-1 must also be in an area with good Wi-Fi coverage.

HOW TO LINK THE CONNECT-1

Choose your case and follow the steps in order

CASE 1 • NEW INSTALLATION

This is the first time you are connecting the Connect-1.

STEP 1	STEP 2	STEP 3
Check the LED If the LED is blinking slowly (once every 2 seconds), go to step 3.	Press reset Using a paperclip, press and hold the reset button for 2 seconds. The LED will start blinking slowly.	Open the app Open MySmartWindow and follow the linking wizard.

CASE 2 • LINK AGAIN

The Connect-1 has already been connected to an account before.

STEP 1	STEP 2	STEP 3	STEP 4
Press reset Using a paperclip, press and hold the reset button for 2 seconds.	Wait Wait 5 seconds without pressing anything.	UP + DOWN Press and hold the UP and DOWN buttons together for about 10 seconds.	Open the app The LED blinks slowly. Open MySmartWindow and follow the wizard.

DONE When linking completes successfully, the app shows the Connect-1 as connected.

WON'T CONNECT? Check that your Wi-Fi is **2.4 GHz**, that there is good coverage where the Connect-1 is installed, and repeat the steps from the beginning.